




Optional transfer sensor for BCM pump with INVERTER



TECHNICAL FEATURES:

- Optional connectable as standard on every BCM pump model with INVERTER
- Transfer function to control trays of all sizes and capacities (e.g. crusher collection tank, press)
- Robust, small and compact sensor
- Excessive sound central alarm
- Detection of sensor faulty or not connected
- Practical, small in size and versatile in use
- LED operating diagnostics



Small "fork" sensor with central warning device in case of excessive level (insufficient pouring for example)

Accessories, spare parts, maintenance and dedicated technical assistance

Company site



Where to access



B.C.M. Macchine Enologiche

Via Veneto 10 Zona Artigianale Saonara (PD)

Tel +39 049-640372 Fax +39 049-5018355

Marketing & Service:

info@bcmenologia.com

www.bcmenologia.com