



Optional fill sensor for BCM pump with INVERTER

Optional filling sensor



Fill sensor model



Automatic / Manual control with the possibility of final filling in manual mode

TECHNICAL FEATURES:

- Optional connectable as standard on every BCM pump model with INVERTER
- Filling function of any size tank
- Also applicable for barrique tanks
- Robust, small and compact sensor with over level warning
- Precise and instantaneous operation when in contact with the liquid
- Detection of sensor faulty or not connected
- Practical, small in size and versatile in use
- LED operating diagnostics

Accessories, spare parts, maintenance and dedicated technical assistance

Company site



Where to access



B.C.M. Macchine Enologiche

Via Veneto 10 Zona Artigianale Saonara (PD)

Tel +39 049-640372 Fax +39 049-5018355

Marketing & Service:

info@bcmenologia.com

www.bcmenologia.com